

GP7132 and GP7136 PARTS LIST

ITEM	PART	DESCRIPTION	QTY.	ITEM	PART	DESCRIPTION	QTY.
1	07600	Crankcase	1	38	06093	Seal Case	3
1A	05525	Head for Oil Dipstick	1	38A	13141	O-Ring, Seal Case	6
1B	01009	O-Ring	1	38B	13142	Support Ring	6
2	13000	Oil Filler Plug Assembly	1	39	06094	Seal Sleeve, GP7132	3
4	07601	Crankcase Cover	1	39	06794	Seal Sleeve, GP7136	3
5	05798	Seal for Cover	1	39A	13360	Grooved Ring, GP7132	3
8	07603	Oil Dip Stick	1	39A	13291	Grooved Ring, GP7136	3
9	01009	O-Ring, Dip Stick	1	41	06095	Pressure Ring, GP7132	3
10	22706	Hexagon Screw	8	41	06795	Pressure Ring, GP7136	3
11	06725	Spring Washer	8	42	06096	V-Sleeve, GP7132	6
12	07109	Drain Plug	5	42	06796	V-Sleeve, GP7136	6
13	06272	Gasket, Drain Plug	5	43	06097-0100	Sleeve Support Ring SS, GP7132	3
14	05644	Bearing Cover	2	43	06797	Sleeve Support Ring, GP7136	3
15	07608	Radial Shaft Seal	2	45	06098	Tension Spring	3
16	07184	O-Ring, Bearing Cover	2	49	13159	Stud Bolt	8
17	05642	Inner Hexagon Screw	8	49A	13160	Nut	8
18	05039	Spring Washer	8	50	06798	Valve Casing	1
20	07610	Taper Roller Bearing	2	51	04727	Inlet Valve Assembly	3
20A	07611	Fitting Disc (Shim)	1-5	51B	05193	O-Ring	3
21	05645	Holder for Shaft Protector	1	51C	04725	Inlet Valve Seat	3
21A	05646	Shaft Protector	1	51D	13130	Valve Plate	3
22	13405	Crankshaft	1	51E	07062-0100	Valve Spring	3
23	07614	Key	1	51F	13147	Spacer Pipe	3
24	13182	Connecting Rod Assembly	3	52	04728	Discharge Valve Assembly	3
24A	07616	Fitting Screw	6	52B	05193	O-Ring	3
24B	08041	Washer	6	52C	04726	Discharge Valve Seat	3
25	13183	Crosshead Assembly	3	52D	13130	Valve Plate	3
28	13184	Crosshead Pin	3	52E	07062-0100	Valve Spring	3
30	07619	Cover Plate	1	52F	13147	Spacer Pipe	3
30A	07225-0100	Hexagon Screw	8	57	06078	Compression Spring	3
30B	13136	Grommet	4	58	07699	Plug	3
30C	08280	Washer	8	58A	07700	O-Ring	3
30D	13154	Cover	1	58B	07693	Support Ring	3
31	07623	Eye Bolt	1	58C	07702	Hexagon Screw	12
32	07624	Radial Shaft Seal	3	60	04576	Plug, 3/4" NPT	1
33	07626	Seal Retainer	3	61	12251	Plug, 1-1/4" NPT	1
33A	07627	O-Ring, Seal Retainer	3	66	13362	Disc for Crankshaft	1
33B	07628	Circlip, Seal Retainer	3	67	13358	Hexagon Screw	1
33C	07249	Shim	3		04367	Manifold Assembly (50-61[w/o 51A], 3 x 51 A-B, 51D-F and 52C)	1
34	13137	Flinger	3		04340	Plunger Conversion Kit, GP7132 (36-45)	1
36	06091	Plunger Assembly (36A-36D) GP7132	3		04177	Plunger Conversion Kit, GP7136 (36-45)	1
36	06792	Plunger Assembly (36A-36D) GP7136	3		17212	Gear End Assembly (1-34, 49, 49A, 50A, 66 and 67)	1
36A	07667	Plunger Connection	3		07662	Valve Tool (not shown)	1
36B	06092	Plunger Pipe, GP7132	3				
36B	06793	Plunger Pipe, GP7136	3				
36C	07664	Tensioning Screw	3				
36D	07665	Copper Ring	3				

GP7132 and GP7136 PUMP REPAIR KITS

Plunger Packing Kits

09519 (GP7132)

Item	Part #	Description	Qty.
38A	13141	O-Ring, Seal Case	6
38B	13142	Support Ring	6
39A	13360	Grooved Ring	3
42	06096	V-Sleeve	6

09544 (GP7136)

Item	Part #	Description	Qty.
38A	13141	O-Ring, Seal Case	6
38B	13142	Support Ring	6
39A	13291	Grooved Ring	3
42	06796	V-Sleeve	6

Oil Seal Kit - # 09221

Item	Part #	Description	Qty.
32	07624	Radial Shaft Seal	3
33A	07627	O-Ring	3

Valve Assembly Kit - #09520

Item	Part #	Description	Qty.
51B	05193	O-Ring	3
51C	04725	Inlet Valve Seat	3
51D	13130	Valve Plate	3
51E	07062-0100	Valve Spring	3
52B	05193	O-Ring	3
52C	04726	Discharge Valve Seat	3
52D	13130	Valve Plate	3
52E	07062-0100	Valve Spring	3
58A	07700	O-Ring	3
58B	07693	Support Ring	3